

ve good weighing results, always use flexible connecti

To achieve good weighing results, always use flexible connections to the vessel and check that no ladders or other arrangements connect the weighed vessel to surrounding foundation, walls or roof.



## Vishay Nobel AB

Box 423, SE-691 27 Karlskoga, Sweden Phone +46 586 63000, Fax +46 586 63099 e-mail: pw.se@vishaypg.com www.weighingsolutions.com Document no. 35126 Publication 850 205 R1 © Vishay Nobel AB, 2010-07-28 Subject to changes without notice.



## Advices for mounting KIMD-1 and KOM-1



